

# HOW TO PERFORM THE CHART TEST

To run a chart test on your recorder:

1. Unplug the unit and disconnect the battery
2. Make sure the knob is snug
3. Press and hold button "3" on the membrane switch while plugging the recorder back in to the outlet; then release button "3"
4. Press and release button "3" again
5. The recorder pen will move beyond the outer edge of the chart and then back to the outer graduation of the chart paper
6. Wait until the LED light begins blinking and then press and release button "1"
7. The chart will start rotating and will end the test where it began

